


# METER CAN BONDING

Internal and External Breaker Cabinets

Phone: 817.444.3201 ★ tcectexas.com


**Internal Breaker Cabinet**



*\*Existing facilities only*


Ground wire must be landed per meter can manufacturer

#6 soft drawn copper




\*\*

**Internal Breaker Cabinet (Side View)**




**External Breaker Cabinet**



Ground wire must be landed per meter can manufacturer

#6 soft drawn copper

Ground wire must be carried through



\*\*

\*\*Refer to [Installation Requirements: Rod + Pipe Electrodes](#) for ground installation